

# i7 series

Elegant Simple  
Unique Sophisticate


White

Champagne

Grey




## Multigang Frames



Customized rockers and frames available in different colours:



Reference colours



## Switches

- 701011 10AX 250V 1 Gang 1 way switch
- 701012 10AX 250V 1 Gang 2 way switch
- 701123 10AX 250V 1 Gang double-pole switch
- 701124 10AX 250V Double-pole 2 way switch
- 701126 10AX 250V 1 Gang intermediate switch
- 701013 10AX 250V 1 Gang 1 way switch with LED indicator
- 701014 10AX 250V 1 Gang 2 way switch with LED indicator
- 701021 10AX 250V 2 Gang 1 way switch
- 701022 10AX 250V 2 Gang 2 way switch
- 701023 10AX 250V 2 Gang 1 way switch with LED indicator
- 701024 10AX 250V 2 Gang 2 way switch with LED indicator
- 701031 10AX 250V 3 Gang 1 way switch
- 701032 10AX 250V 3 Gang 2 way switch
- 701033 10AX 250V 3 Gang 1 way switch with LED indicator
- 701034 10AX 250V 3 Gang 2 way switch with LED indicator
- 702023 20AX 250V 1 Gang 1 way double-pole switch with blue LED indicator
- 702024 20AX 250V 1 Gang 2 way double-pole switch with blue LED indicator
- 703223 32AX 250V 1 Gang 1 way double-pole switch with red LED indicator
- 703224 32AX 250V 1 Gang 2 way double-pole switch with red LED indicator

## Push buttons

- 701011F 10AX 250V 1 Gang push-button switch
- 701021F 10AX 250V 2 Gang push-button switch
- 701031F 10AX 250V 3 Gang push-button switch
- 706301 10AX 250V Doorbell switch
- 70E611 10AX 250V Doorbell switch with "Do not disturb"
- 70E612 10AX 250V Doorbell switch with "Do not disturb" and "Make Up Room" indicator
- 70E613 10AX 250V Doorbell switch with "Wait A Minute", "Do Not Disturb" and "Make Up Room" indicator

## Sockets outlets

- 701382 13A British socket with switch
- 701072 10A Twin 2-pin socket for flat and round pins
- 701080 Multiple socket
- 701089 Multiple socket with switch

## Telephone, TV and data sockets

- 705214 Telephone outlet for RJ11 connector
- 705218 Data outlet for RJ45 connector Cat.5e
- 705618 Data outlet for RJ45 connector Cat.6
- 705224 Twin telephone outlet for RJ11 connector
- 705228 Twin data outlet for RJ45 connector Cat.5e
- 705628 Twin data outlet for RJ45 connector Cat.6
- 705119 Twin TV outlet
- 705229 Telephone for RJ11 connector and data for RJ45 connector Cat.5e outlet
- 705629 Telephone for RJ11 connector and data for RJ45 connector Cat.6 outlet
- 705111 TV outlet
- 705302 TV and data for RJ45 connector Cat.5e outlet
- 705602 TV and data for RJ45 connector Cat.6 outlet
- 705114 Shielded TV outlet F type connector
- 705301 TV and telephone for RJ11 connector outlet
- 705119S TV and TV F type connector outlet

## Control and regulation

- 70E101 500W Dimmer switch for incandescent load
- 70E401 160W Voice and light switch
- 70E301 160W Presence detector switch
- 70E501 160W Touch time delay switch
- 70E621 4-Channel volume control switch (3 wiring)
- 70E622 4-Channel volume control switch (7 wiring)
- 70E623 Volume control switch
- 705402 Twin speaker outlet
- 705401 Speaker outlet
- 70E201 200W Fan speed control switch

## Others

- 701000 Blank Plate
- 70E601 20A Card Switch
- 705901 Emergency Switch
- 700495 VGA-3.5 outlet
- 700493 AV-S outlet
- 700494 USB-HDMI outlet
- 70E723 Double USB charger
- 714504 Shaver